

9-1-1 EMERGENCY DRIVE-THRU SYSTEM

INSTALLATION & OPERATION

INDOOR STATION

1. The #0912 Indoor Station is mounted on a movable stand that may be easily positioned for operating convenience.
2. Plug one end of the audio cable into the audio jack on the bottom of the indoor speaker housing.
3. Plug the #0287 cable into the power jack on the bottom of the housing and the #0250 transformer into a nearby electric outlet.
4. A jack can be provided for an optional #0880 Footswitch.

OUTDOOR STATION

1. Pass the audio cable through the drive-thru window and run it along the curb or building to the menu board speaker post.
2. Plug the brown audio cable into the jack on the bottom of the #0913 Outdoor Speaker Housing.
3. Insert the hooks on the rear of the housing into the perforated grill on the menu board or speaker post.
4. Fit the #0390 air hose onto the tube extending from the bottom of the #0913 Outdoor Station and attach #0852 anchor.
5. Lay the hose on the driveway, straight out from the speaker. (To keep the hose from being pulled off speaker, wrap it around the base of the menu board once).

STORAGE

1. Remove the audio and power cables and place the indoor station on it's side in the carrying case.
2. Coil the power cable and place it in the case.
3. Remove the audio cable and air hose from the outdoor speaker and place the housing in the carrying case.
4. Coil and secure the air hose and set it in the case next to the housings.
5. Wrap the audio cable around the cable winding frame and lay it on top of the other components.

OPERATION

1. As soon as power is applied to the #0911 EDTS it is in "READY" mode.
2. When a vehicle drives over the air hose:
 - The indoor speaker will beep
 - The red LED on the speaker grille will light
 - The audio from the vehicle will be "ON"
3. To speak to the vehicle:
 - Press the "TALK" button and talk in a normal voice
4. To hear the customer's order:
 - Release the "TALK" button
5. To turn "OFF" the audio and return to "READY" mode:
 - Press the "OFF" switch

Note: The "OFF" switch doesn't turn off power. If it is necessary to shut the system off completely, unplug the transformer from the outlet.

6. The indoor speaker volume can be adjusted by turning the knob on the bottom of the indoor speaker.

911 EDTS PARTS LIST

- 1 - 0250 Transformer
- 1 - 0287 Power Cable
- 1 - 0681 Mounting Stand
- 1 - 0852 Hose Anchor
- 15' - 0390 Air Hose
- 1 - 0910 Carrying Case
- 1 - 0913 Outdoor Station
- 1 - 0914 100' Input/Output Cable
- 1 - 0912 Indoor Station

MARSH
PRODUCTS, INC
Spectrum Companies Int'l Ltd

336 McKee Street
Batavia IL 60510
Tel • 630-879-8008
Fax • 630-879-8072